


# COMPLI 500


Ersatzteile - Spare parts - Pièces de rechange - Reserveonderdelen - Parti di ricambio - Reservedele - Reserv



①	Steuerung	Control unit
	510/4, 515/4	
	525/2, 525/4	
	535/2	
②	DN150 / DN100	DN 150 / DN100
③		
④		
⑤		
⑥		
⑦		
	510/4, 515/4	
	525/2, 525/4	
	535/2	
⑧		
⑨		
⑩		
⑪		
	510/4	
	515/4	
	525/4	
	525/2	
	535/2	
⑫		
⑬		
⑭		
⑮		
⑯		



①	Steuerung	Control unit
	1010/4 BWE	
	1010/4, 1015/4	
	1025/4, 1025/2	
	1035/2	
②	DN 150 / DN 100	DN150 / DN 100
③		
④		
⑤		
⑥		
⑦		
⑧		
	4 m Leitung	
	15 m Leitung	
⑨		
⑩		
⑪		
	1010/4 BWE, 4 m	
	1010/4 BWE, 15 m	
	1010/4	
	1015/4	
	1025/4	
	1025/2	
	1035/2	
⑫		
⑬		



①	Leitung	Cable	
	10/4, 15/4, 25/4		<b>JP43717</b>
	1010/4 BWE, 4 m		<b>JP43721</b>
	1010/4 BWE, 15 m		<b>JP48685</b>
②	Stator + Gehäuse	Stator + Housing	
	10/4, 15/4, 25/4		<b>JP47042</b>
	1010/4 BWE		<b>JP43722</b>
③	Rotorwelle	Rotor shaft	
	10/4, 15/4, 25/4		<b>JP45791</b>
	1010/4 BWE		<b>JP46801</b>
④	Motorabdichtung	Motor seals	<b>JP46806</b>
⑤	Lauf radbefestigung	Impeller fixation	
	10/4, 15/4, 25/4		<b>JP46802</b>
	1010/4 BWE		<b>JP46803</b>
⑥	Lagersatz	Bearing set	<b>JP46724</b>
⑦	Lagerschild	Bearing housing	<b>JP43720</b>
⑧	Dichtungssatz	Seal set	<b>JP46807</b>
⑨	Lauf rad	Impeller	
	1010/4 BWE		<b>JP47290</b>
	10/4		<b>JP45793</b>
	15/4		<b>JP45794</b>
	25/4		<b>JP45795</b>
⑩	Schraubensatz	Screw set	<b>JP47291</b>

